

# Asbestos Abatement Worker Skilled Trade Test Mock Written Test Paper

此文件關於清拆石棉大工工藝測試考題有需要索取此文件的中文版本,請致電 2100 9232 與工藝測試中心 聯絡。

#### Disclaimer

No part of this material may be reproduced or transmitted in any form or any means without the written permission of the CIC. Whilst reasonable efforts have been made to ensure the accuracy of the information contained in this material, the CIC nevertheless would encourage readers to seek appropriate independent advice from their professional advisers where possible and readers should not treat or rely on this material as a substitute for such professional advice for taking any relevant actions.

#### Enquiries

Enquiries on this Material may be made to the Trade Test Centre at:

95, Yue Kwong Road Aberdeen Hong Kong

Tel: (852) 2100 9232 Fax: (852) 2100 9249 Email: enquiry@cic.hk Website: <u>www.cic.hk</u>

© 2015 Construction Industry Council.

# **Asbestos Abatement Worker**

1. The age of an asbestos abatement worker should be:

- (a) Over 14
- (b) Over 18
- (c) Over 21
- (d) Over 21 or under 40

2. When constructing an enclosed working area, how many layers of plastic canvas should be put on the solid wall?

- (a) 1
- (b) 2
- (c) 3
- (d) 4

3. What category of waste does intact amosite waste belong to?

- (a) Category 1
- (b) Category 2
- (c) Category 3
- (d) Category 4

4. The occupational health standard of crocidolite or amosite is:

- (a) 0.2 fibre/ml
- (b) 0.2 amosite fibre/ml
- (c) 0.5 fibre/ml
- (d) 0.5 amosite/ crocidolite fibre/ml

- 5. Application for disposal of 100 m<sup>3</sup> asbestos waste must be submitted:
  - (a) One working day before
  - (b) 10 working days before
  - (c) 4 working days before
  - (d) 5 working days before
- 6. The thickness of the transparent plastic sheet of the inspection window should be at least:
  - (a) 1.5 mm
  - (b) 2.0 mm
  - (c) 2.5 mm
  - (d) 3.0 mm
- 7. In the asbestos abatement plan, a 3-chamber decontamination chamber should be constructed if the working area exceeds:
  - (a) 10 m<sup>2</sup>
  - (b) 15 m<sup>2</sup>
  - (c) 20 m<sup>2</sup>
  - (d) 25 m<sup>2</sup>

8. Asbestos waste should be stored in:

- (a) Refuse bin
- (b) Refuse collection station
- (c) Enclosed area
- (d) Specified storage location

# Knowledge Section

# 9. The medical checkup for asbestos abatement worker includes:

- (a) Annual checkup
- (b) Pre-employment checkup
- (c) Free checkup provided by the employer
- (d) All the above

#### 10. Asbestosis is:

- (a) Pleural calcification
- (b) Local skin fibrosis
- (c) Kind of lung cancer
- (d) Pulmonary fibrosis

# 11. Which of the following asbestos abatement work can be carried out in the open environment?

- (a) Asbestos balcony grille panel
- (b) Acoustic plaster
- (c) Asbestos pipe insulation
- (d) Asbestos fire protection layer

#### 12. Long-term inhalation of asbestos fibre may lead to:

- (a) Asbestosis
- (b) Lung cancer
- (c) Mesothelioma
- (d) All the above

# 13. Which of the following is a low-risk asbestos containing material?

- (a) Dismantled insulation plaster
- (b) Damaged vehicle brake pad
- (c) Intact asbestos sheet
- (d) Burst sand brick

- 14. What category of people will have asbestosis?
  - (a) Adults
  - (b) Young persons
  - (c) Juveniles
  - (d) All the above

# Safety Section

- 15. Before going off, all dismantled asbestos waste must be:
  - (a) Cleaned and neatly piled, cleared up after completion
  - (b) Wet-treated and removed from working area after packed properly
  - (c) Vacuumed and cleaned (large pieces), packaged and disposed
  - (d) Left behind for clean up by workers of next shift
- 16. Which of the following environments will workers get heat stroke more easily?
  - (a) Locations without air-conditioning
  - (b) Hot and humid environment
  - (c) Environment without cover but raining
  - (d) Office
- 17. Which of the following effects to health is not due to incorrect load lifting?
  - (a) Varicose veins
  - (b) Hernia (commonly known as intestinal gas)
  - (c) Low back sprain
  - (d) Hypertension
- 18. When entering a site, the law requires that you must wear:
  - (a) Cotton gloves
  - (b) Safety belt
  - (c) Helmet
  - (d) Ear plugs

19. Which method should be used to connect electric cords in open air on site?

- (a) Double circuit
- (b) Waterproof connection
- (c) Wrap up with adhesive tape
- (d) Universal adapter

# 20. When working in a high noise level environment, you should:

- (a) Wear radio earphones
- (b) Put tissues in the ears
- (c) Put cotton in the ears
- (d) Wear appropriate ear protectors