HONG KONG CONSTRUCTION INDUSTRY TRADE TESTING CENTRE 香港建造業工藝測試中心

Carpenter (Formwork-Civil Construction) Intermediate Trade Test Study Material for Written Test

(Version: ICC-SM-EN-02)



此文件關於木模板工(土木工程)中級工藝測試技術知識測試(筆試)內容參考資料。如需索取此文件的中文版本,請致電 2100 9000 與香港建造業工藝測試中心聯絡。

Carpenter (Formwork-Civil Construction)
Intermediate Trade Test
Study Material for Written Test

Version: ICC-SM-EN-02

Disclaimer

No part of this material may be reproduced or transmitted in any form or by any means without the written permission from the Construction Industry Council (CIC). Whilst reasonable efforts have been made to ensure the accuracy of the information contained in this material, the CIC nevertheless would encourage readers to seek appropriate independent advice from their professional advisers where possible and readers should not treat or rely on this material as a substitute for such professional advice for taking any relevant actions. The CIC will not assume any liability in relation to any loss or damage directly or indirectly resulted from unintended or/and unforeseeable use of this document.

This document is provided as reference for test preparation only. Under all circumstances all content in the official test papers, including but not limited to the terms and conditions therein, prevails.

The CIC reserves the right, at its sole and absolute discretion, to change, update or delete the contents in this document at any time without prior notice.

The CIC reserves all rights of final interpretation for any content in this document.

Enquiries

Enquiries on this material may be made to Hong Kong Construction Industry Trade Testing Centre at:

Address: 95 Yue Kwong Road, Aberdeen, Hong Kong

Tel: (852) 2100 9000 Fax: (852) 2100 9090 Email: hkcittc@cic.hk Website: www.cic.hk

Version: ICC-SM-EN-02

Carpenter (Formwork-Civil Construction) Intermediate Trade Test Study Material for Written Test

This study material is a reference for candidate to prepare for attending written test in Intermediate

Trade Test:

- 1. For a good formwork, gaps between the strips should be less than 1mm.
- 2. When fabricating a wooden formwork, the most common type of nail used is 2-inch common nail.
- 3. The function of installing water stop at the joint between two sections of retaining wall is to prevent water seepage.
- 4. Formwork for fair-face concrete surface is most commonly used in retaining walls and flyover.
- 5. The purpose of providing a temporary flexible opening (cleanout port) at column or wall toe is to make it easy to remove debris and scrap.
- 6. For formwork construction of water tank and retaining wall, coil type form tie should be used instead of plastic (PVC) cone spreaders to tie the formwork in order to prevent water from seeping into the wall.
- 7. To strengthen the support, wooden ties should be connected to the wood post shore/prop.
- 8. The overall components of the completed formwork should have sufficient strength, rigidity and stability.
- 9. For a standalone column formwork with size of 0.9m x 0.9m x 2.5m height, four bracings should be used at the corners.
- 10. The purpose of applying mould oil/release agent on the formwork is to prevent concrete from sticking to the formwork.
- 11. The prop, stringer and joist of timber formwork are the main load bearing components.

 Normally, it is made of smooth, straight and tough materials.
- 12. To prevent water seepage, the plastic cone and plastic sleeve/tube for form tie left on outer wall of buildings should be removed and filled by cement mortar.

Version: ICC-SM-EN-02

- 13. To push the remaining material when planing or cutting timber on a woodworking machine tool, push-block (crimp fitting plane base) or push stick (forked pushing) should be used.
- 14. To saw timber floor with a required angle, it is more appropriate to use mitre saw with an adjustable angle.
- 15. If the electrical tool is malfunction, worker should stop operating the tool and report to the supervisor to arrange for repairing.
- 16. The sawdust and fillings should be clean and putted into the rubbish bin after sawing.
- 17. On construction site, it is prohibited to burn the construction waste.
- 18. The minimum width of the working platform for a double-layered scaffold should be not less than 400 mm.
- 19. When working on site, safety shoes should be worn to protect the feet.
- 20. During at work on construction site, it is inappropriate to consume alcoholic drinks.

Precautions

This document is provided as reference for test preparation only. Under all circumstances all content in the official test papers, including but not limited to the terms and conditions therein, prevails. There are different versions of the test paper, content include but not limited to tools, materials, equipment, drawing, construction details or procedures and different simulated site environments. Candidates should refer to the official test documents during testing.

The CIC reserves the right, at its sole and absolute discretion, to change, update or delete the contents in this document at any time without prior notice.